

HP MODELS		
OD Model		TXV+
TH4B	1821S	BA1
	2421S	BA1
	3021S	BB1
	3521S	BE1
	3621S	BF1
	4221H	BF1
	4822S	BC1
	6022S	BG1
CH16B	2421S	BA1
	3621S	BC1
	4821S	BC1
	6121S	BG1
		5729044-CTD-0419
THE	30B(3,4)1S	BB1 or BE1
	36B(3,4)1S	BF1
	42S(3,4)1S	BF1
	48S(3,4)1S	BC1
	60S(3,4)1S	BG1
RHP14L	18B21S	BA1
	24B21S	BA1
	30B21S	BB1 or BE1
	35B21S	BE1
	36B22S	BA1
	42B22S	BC1
	48B22S	BC1
	60B22S	BG1

CURRENT OD Model			TXV+
TH4B	1821S		BA1
	2421S		BA1
	3021S		BA1 OR BB1
	3521S		BA1 OR BB1
	3622S		BA1 OR BF1
	4222S		BC1
	4822S		BC1
	6022S		BC1 OR BG1
			5565506-BTD-E-0819
CH6B	1821S		BA1
	2421S		BA1
	3021S		BA1
	3621S		BA1 OR BB1
	4221S		BC1
	4821S		BC1
	6021S		BC1 OR BD1
			5485804-ctd-e-0220
RHP14L	18B23S		BA1
	24B23S		BA1
	30B23S		BB1 or BB1
	35B23S		BA1 OR BB1
	36B23S		BA1 OR BF1
	42B24S		BC1
	48B23S		BC1
	60B23S		BC1 or BG1
		5612272-UTG-G-0620	

Note:

Remember the metering device ALWAYS follows the out door unit.

		Nominal Capacity	Cabinet width	TXV installed x=none
A	P	24	B	BA
A	E	36	A	BB
C	M	48	C	BC

*Source 1 TXV part number- S1-1TMV(xxx)



How to tell the factory installed metering device